

7 steps of servo modification:

- 1) Modify SG90 servo motor for continuous rotation.
- 2) Remove gear that drives potentiometer.
- 3) Snip off a few mm of drive shaft.
- 4) Trim off lugs.
- 5) Set potentiometer to neutral position.
- 6) Reassemble.
- 7) Test.

